

SINCE 1925

KEYSTONE

SAFETY

CONTROLLED ENVIRONMENT FROCK

CEFO-WE-SMS-WHITE

DESCRIPTION: SMS-NO POCKET-ELASTIC WRISTS-MANDARIN COLLAR-6 SNAPS ELASTIC BAND THUMB LOOPS AND HANGER LOOP- ANTI STATIC TREATMENT

Keystone's SMS three layer material is soft and durable, which makes it easy to work with. Two layers of spunbonded polypropylene enhanced with an inner layer of meltblown polypropylene offers excellent barrier protection while keeping the worker cool and does not sacrifice mobility or comfort. These cleanroom compatible frocks are low shedding, low in particulate, and are anti-static to protect sensitive products. SMS Frocks are an excellent particulate barrier and liquid repellent. The extra-long, knee-length frocks protect the controlled environment from the number one source of contamination found in cleanrooms - people. The mandarin collar and the six-snap front provide better protection than the traditional lab coat. The elastic cuffs with thumb loops make donning gloves easier and prevents exposed wrists and forearms on your production floor.



FEATURES

BENEFITS

SMS Fabric	<ul style="list-style-type: none"> Low lint, low particulate, excellent particulate barrier Fluid resistant Antistatic treated to protect sensitive products
Thumb Loop	Improves glove donning by preventing the sleeve from sliding up during the donning process
Hanger Loop	Ease of storing garments on breaks and in lockers if needed
Mandarin Collar	Provides more complete closure, eliminated the issues associated with lapel style collars
Knee-Length	Directs contaminants generated from wearer away from critical sites to areas well below the work surface

Applications: Commonly used in cleanrooms, laboratories, medical and pharmaceutical industries.

All Keystone Safety Product components comply with the provisions of the Federal Food, Drug and Cosmetic Act, which allow repeated use in direct contact with food. Fabric conforms to FDA code of Federal Regulations Title 21, Rule 110.10 & 177.1950

ITEM	SIZE	COUNT	WT/BOX	DIMENSION	CUBE	QUANTITY/ SKID	SKID CONFIG TIERS x ROWS
CEFO-WE-SMS	SM	30/cs	7	13x11x14	.032	72	12x6
CEFO-WE-SMS	MED	30/cs	8	13x11x14	.032	72	12x6
CEFO-WE-SMS	LRG	30/cs	8.2	13x11x14	.032	72	12x6
CEFO-WE-SMS	XL	30/cs	8.2	13x11x14	.032	72	12x6
CEFO-WE-SMS	2XL	30/cs	8.2	13x12x14	.036	72	12x6
CEFO-WE-SMS	3XL	30/cs	8.6	13x12x14	.036	72	12x6
CEFO-WE-SMS	4XL	30/cs	8.6	13x12x14	.036	72	12x6
CEFO-WE-SMS	5XL	30/cs	9.6	13x12x14	.036	72	12x6

TOLL FREE (800) 663.5439
TOLL FREE FAX (800) 663.5432
PHONE (856) 663.5740
FAX (856) 663.6075

1591 HYLTON ROAD
PENNSAUKEN, NJ 08110
KEYSTONESAFETY.COM
INFO@KEYSTONESAFETY.COM

SINCE 1925

KEYSTONE

SAFETY