

SINCE 1925

KEYSTONE

SAFETY

CONTROLLED ENVIRONMENT FROCK

CEF3-BK-SMS-BLUE

DESCRIPTION: SMS-3 POCKET-KNIT WRISTS-KNIT COLLAR-6 SNAPS-ELASTIC BAND THUMB LOOPS AND HANGER LOOP-ANTI STATIC TREATMENT

Keystone's SMS disposable Frock is manufactured from a specially formulated material that makes these garments highly breathable and provides great comfort and protection. These ISO Class 6 cleanroom compatible frocks are low shedding, low in particulate, and are antistatic to protect sensitive products. SMS Frock is an excellent particulate barrier and liquid repellent.

The extra-long, knee-length frock protects the controlled environment from the number one source of contamination found in cleanrooms --- people. The knit collar and the six-snap front provide better protection than the traditional lab coat. The knit cuffs with thumb loops make donning gloves easier and prevents exposed wrists and forearms on your production floor.



FEATURES

BENEFITS

SMS Fabric	<ul style="list-style-type: none"> Low lint, low particulate, excellent particulate barrier Fluid resistant Antistatic treated to protect sensitive products
Thumb Loop	<ul style="list-style-type: none"> Improves glove donning by preventing the sleeve from sliding up during the donning process
Hanger Loop	<ul style="list-style-type: none"> Ease of storing garments on breaks and in lockers if needed
Knit Cuff	<ul style="list-style-type: none"> Provides tapered fit which improves glove donning and user comfort
Knee-Length	<ul style="list-style-type: none"> Directs contaminants generated from wearer away from critical sites to areas well below the work surface
Knit Collar	<ul style="list-style-type: none"> Provides more complete closure, eliminating the issues associated with lapel style collars

Applications: Designed for controlled environments where fibers and particulate contamination is a concern. Asbestos Abatement, food processing, paint spraying, pesticide spraying, fiberglass handling, lab/biohazards, cleanroom, medical, general cleaning, metal surface treating, pharmaceutical industry. This product is recommended for either stringent industrial or demanding cleanroom applications. This coverall is ideal for use in a cleanroom Class 1-10 (ISO 3-4) critical environment as well as other critical areas that require high contamination control and cleanliness.

All Keystone Safety Product components comply with the provisions of the Federal Food, Drug and Cosmetic Act, which allow repeated use in direct contact with food. Fabric conforms to FDA code of Federal Regulations Title 21, Rule 110.10 & 177.1950

ITEM	SIZE	COUNT	WT/BOX	DIMENSION	CUBE	QUANTITY/ SKID	SKID CONFIG TIERS x ROWS
CEF3-BK-SMS	SM	30/cs	7.6	14x11x17	.040	60	12x5
CEF3-BK-SMS	MED	30/cs	7.8	14x11x17	.040	60	12x5
CEF3-BK-SMS	LRG	30/cs	7.8	14x11x17	.040	60	12x5
CEF3-BK-SMS	XL	30/cs	8.4	14x11x17	.040	60	12x5
CEF3-BK-SMS	2XL	30/cs	8.8	14x11x17	.044	60	12x5
CEF3-BK-SMS	3XL	30/cs	9.4	14x11x17	.044	60	12x5
CEF3-BK-SMS	4XL	30/cs	9.8	14x11x17	.044	60	12x5
CEF3-BK-SMS	5XL	30/cs	10.4	14x11x17	.044	60	12x5

TOLL FREE (800) 663.5439
TOLL FREE FAX (800) 663.5432
PHONE (856) 663.5740
FAX (856) 663.6075

1591 HYLTON ROAD
PENNSAUKEN, NJ 08110
KEYSTONESAFETY.COM
INFO@KEYSTONESAFETY.COM

SINCE 1925

KEYSTONE

SAFETY