

SINCE 1925

# KEYSTONE

## SAFETY

# CONTROLLED ENVIRONMENT FROCK

## CEF3-WK-SMS-WHITE

### DESCRIPTION: SMS-3 POCKET-KNIT WRISTS-KNIT COLLAR-6 SNAPS-ELASTIC BAND THUMB LOOPS AND HANGER LOOP-ANTI STATIC TREATMENT

Keystone's SMS disposable Frock is manufactured from a specially formulated material that makes these garments highly breathable and provides great comfort and protection. These ISO Class 6 cleanroom compatible frocks are low shedding, low in particulate, and are anti-static to protect sensitive products. SMS Frocks are an excellent particulate barrier and liquid repellent.

The extra-long, knee-length frocks protect the controlled environment from the number one source of contamination found in cleanrooms --- people. The knit collar and the six-snap front provide better protection than the traditional lab coat. The knit cuffs with thumb loops make donning gloves easier and prevents exposed wrists and forearms on your production floor.



### FEATURES

### BENEFITS

SMS Fabric	<ul style="list-style-type: none"> <li>Low lint, low particulate, excellent particulate barrier</li> <li>Fluid resistant</li> <li>Antistatic treated to protect sensitive products</li> </ul>
Thumb Loop	<ul style="list-style-type: none"> <li>Improves glove donning by preventing the sleeve from sliding up during the donning process</li> </ul>
Hanger Loop	<ul style="list-style-type: none"> <li>Ease of storing garments on breaks and in lockers if needed</li> </ul>
Knit Cuff	<ul style="list-style-type: none"> <li>Provides tapered fit which improves glove donning and user comfort</li> </ul>
Knee-Length	<ul style="list-style-type: none"> <li>Directs contaminants generated from wearer away from critical sites to areas well below the work surface</li> </ul>
Knit Collar	<ul style="list-style-type: none"> <li>Provides more complete closure, eliminating the issues associated with lapel style collars</li> </ul>

**Applications:** Designed for controlled environments where fibers and particulate contamination is a concern. Asbestos Abatement, food processing, paint spraying, pesticide spraying, fiberglass handling, lab/biohazards, cleanroom, medical, general cleaning, metal surface treating, pharmaceutical industry.

All Keystone Safety Product components comply with the provisions of the Federal Food, Drug and Cosmetic Act, which allow repeated use in direct contact with food. Fabric conforms to FDA code of Federal Regulations Title 21, Rule 110.10 & 177.1950

ITEM	SIZE	COUNT	WT/BOX	DIMENSION	CUBE	QUANTITY/ SKID	SKID CONFIG TIERS x ROWS
CEF3-WK-SMS	SM	30/cs	9.2	13x11x14	.032	72	12x6
CEF3-WK-SMS	MED	30/cs	9.6	13x11x14	.032	72	12x6
CEF3-WK-SMS	LRG	30/cs	10	13x11x14	.032	72	12x6
CEF3-WK-SMS	XL	30/cs	10	13x11x14	.032	72	12x6
CEF3-WK-SMS	2XL	30/cs	10.2	13x12x15	.036	72	12x6
CEF3-WK-SMS	3XL	30/cs	10.6	13x12x15	.036	72	12x6
CEF3-WK-SMS	4XL	30/cs	12.4	13x12x15	.036	72	12x6
CEF3-WK-SMS	5XL	30/cs	13	13x12x15	.036	72	12x6

TOLL FREE (800) 663.5439  
TOLL FREE FAX (800) 663.5432  
PHONE (856) 663.5740  
FAX (856) 663.6075

1591 HYLTON ROAD  
PENNSAUKEN, NJ 08110  
KEYSTONESAFETY.COM  
INFO@KEYSTONESAFETY.COM

SINCE 1925

# KEYSTONE

## SAFETY